Play Music on Another Smart Device

- 1. On the currently paired device, end the connection by:
- Disabling Bluetooth or disconnecting TP-Link Music, or
- Placing its back against the NFCTag or Music Receiver (only for NFC-enabled Android devices)
- 2. On another device, pair to the Music Receiver, then play and enjoy music!

Bonus Tips

After pairing a second device, you can restore connection of the former device to enjoy music from them *in turns*. Simply pause music on one device and play on the other one.

Note that audio may delay when switching from an iOS device.









FAO

Q1. Why can't I pair the Music Receiver?

- A. The Music Receiver is ready to be paired only when its LED turns white. Check the LED.
- If it is off, re-plug the power cable or try another power outlet.
- If it is blue, check your other paired devices and end the connection.

Q2. What can I do if my music does not come out from my stereo?

- A1. Make sure your smart device and the Music Receiver are successfully connected, within 20 meters (66 feet) of each other, and within a direct line of sight. The Music Receiver will be disconnected if your device's Bluetooth signal is blocked, interfered, or out of range for longer than 5 minutes.
- A2. Make sure your stereo and the Music Receiver are correctly connected via one of the provided audio cables, and both are powered on.
- A3. Make sure the volume on your music player and stereo are at an audible level.



For more information, please visit:

www.tp-link.com Technical Support

Tel: +86 755 2650 4400 E-mail: support@tp-link.com

Web: http://www.tp-link.com/support



©2017 TP-Link 7106507772 REV2.0.2



HA100 | Ouick Start Guide




NFC-Enabled Bluetooth® Music Receiver

Bringing Bluetooth to your home stereo

Connect

Add Bluetooth to your home stereo as shown. The LED on the Music Receiver will turn white.



^{*} Two audio cables are provided. Choose the one that suits your home stereo.



Method 1: Bluetooth pairing

- 1. On your smart device, enable Bluetooth in **Settings**.
- 2. Pair TP-Link Music in the list of found devices.

Method 2: NFC pairing (Only for NFC-equipped Android devices)

- 1. On your Android device, enable NFC (Near Field Communication) in Settings.
- 2. Place the back of your device against the Music Receiver or provided NFC Tag until the pairing request pops up.
- 3. Confirm the pairing request.





It's music time!

Keep in mind that you can play your music from up to 20 meters (66 feet), within a direct line of sight.



More: Want to play music on another smart device? Flip the paper for instructions.